

Assembly & ordering checklist

Before installation

- Isolate and release stored pressure before opening any hydraulic connection.
- Confirm tube, series and matched components. Prepare the tube square, deburred and clean.
- Use the required preassembly tools, lubrication and inspection method.
- Follow the supplied final assembly procedure; no single torque or turn count applies to every system.
- Support the tube, check alignment and inspect during controlled commissioning.
- Inspect dismantled components and follow the specified reassembly procedure.

Send these details with your enquiry

Field	Required detail
Configuration	Name, quantity and marked sketch or photograph
Tube	OD, wall thickness, material and LL/L/S series
Ports	Type, size, pitch and seal at every connection
Duty	Fluid, pressure including peaks, temperature range
Supply	Complete fitting / body only / matched spare
Documents	Required drawing and supporting documentation

F-LINE hydraulic systems & fittings

ram@fluidline.co.za | brett@fluidline.co.za

+27 11 312 9339 | www.fluidline.co.za

Use the full catalogue for the configuration selector and dimensional reference. The approved order-specific drawing and supplied assembly instructions govern the actual item. Reference edition: October 2026.